

METHODOLOGY FOR APPLICATION OF MYK GROUT INJECT E-200

Description:

MYK Grout Inject E-200 is two components, low viscous Epoxy resin injection grouting material, grouting gaps ranging from 0.3mm to 10mm. It gives high compressive, tensile and flexural strength.

Packing: 2 and 4.5 Kg pack

Methodology for Application:

Step-1:- Mixing of **MYK Grout Inject E-200**

Step-2:- Application of **MYK Grout Inject E-200**

Mixing of MYK Grout Inject E-200:

The preweighed component of **MYK Grout Inject E-200** has to be mixed thoroughly with mechanical stirrer until a homogeneous mix of uniform colour is obtained.

Application of MYK Grout Inject E-200:

Drilling with electric drilling machines along the honey combed area and wall floor joints and fixing PVC nozzles. Pressure grouting should be carried by using hand operated grouting machine through the nozzles starting from one nozzle and stopping the operations when the grout starts coming out from adjacent nozzle, this is done similarly in all the nozzles.

Consumption:

1.06 kg of material is required for filling of 1000cc.

Protection:

MYK Inject E-200 should be applied with gloves and care should be taken to see that it doesn't fall on screen or eyes. Splashes on the eyes have to be immediately washed with plenty of water and medical advice to be taken.

Note: - All consumptions mentioned above are theoretical and under laboratory conditions, MYK Schomburg strongly recommends site trials to ascertain actual consumptions.